

ST TRACKPARTS

**BMW E87 M2
Rear Wheel Well Vents
& Rear Bumper Reflector Ducts
Install Guide**

1. Remove rear bumper cover and plastic wheel well covers.

LEFT SIDE

2. Align the top of the cover plate with the hole, as demonstrated in the picture.



3. Mark the hole to cut and also mark the bolt holes.

4. Cut the hole and drill the bolt holes.

5. Testfit the duct to see if it fits properly.
6. If it fits then mount the wheel well and mark where the duct touches the wheel well.
7. Remove the wheelwell cover.
8. Cut and drill the wheelwell cover.
9. Mount the wheel well cover again.
10. Finish installation using the included cover plate marked "in". Make adjustments where necessary.



RIGHT SIDE

1. Align the right side outlet marking template vertically to the middle of the area. Align the right side (with the extension) to the right side of the area.
2. Mark the inside of the template and the bolt hole.
3. Cut and drill the markings.
4. Mount the duct using the included tab as a washer.



RIGHT SIDE

5. Mount the wheel well cover and mark where the duct touches.
6. Cut and drill the markings.
7. Finalize mounting using the included cover plate (marked with "in").
8. Enjoy!

