

ST TRACKPARTS

**BMW G82 M4
Rear Wheel Well Ducts Kit
Install Guide**

1. Preparation: Remove rear wheels, wheel vents & loosen rear bumper.
2. Cut the wheel well duct holes in the wheel wells. Use the included cutting templates. Align between the marked holes, and against the edge.



3. Mark the cutting area and bolt holes.



4. Cut the marked area precisely (dremel tool recommended).
5. Drill the bolt holes with 5mm drill bit.
6. The wheel well duct should drop right in.
7. Use the sandwich plate to tighten.
8. Repeat for the other side.



9. Remove the reflectors.

10. Cut the bumper behind the reflectors (only the flat area). We recommend a dremel tool with the sanding bit. Start from the existing holes.



11. Install the duct and reflector (they are magnetically attached).
12. Install wheel well loosely.
13. Attach the hose to the wheel well vent and the reflector duct using the provided hose clamps.
14. If needed, cut away plastic to make space for the hose.



15. Reinstall rear bumper and wheel well cover.
16. Enjoy!

