

# ***ST TRACKPARTS***

## **BMW M2 Reflector Deletes Install Guide**

Tools needed: 8mm socket, T20 Torx  
socket & (long) pliers

1. Remove the rear wheel. Remove the following screws using an 8mm socket.



2. Pull away the wheel liner to expose the screw which connects the bumper.  
Remove using a T20 Torx socket.





3. Now you can pull the bumper to access the reflector. Use (long) pliers to press in the clips. We recommend to start from the top.



4. Simply click in the ST Trackparts reflector deletes and reinstall the bumper and wheel. Repeat for the other side. Done!

