ST TRACKPARTS

INSTALLATION GUIDE

BMW E92 NON-M

# FRONT CANARDS

FRONT AERO CANARD SET · ADHESIVE MOUNT



| DIFFICULTY | EST. TIME | MOUNT | PART NO. |
|---|---|---|---|
| Beginner | 10 – 30 min | 3M VHB Tape | STT-E92-CAN |

# WHAT YOU'LL NEED.

These canards mount with pre-applied VHB adhesive — no drilling. The whole job is surface prep, careful positioning, and firm pressure. Work on a clean, dry car above 15 °C for the best bond.

## WHAT YOU NEED

- CANARDS — LEFT + RIGHT ×2
- PRE-APPLIED VHB TAPE fitted
- ALCOHOL PREP WIPE ×2

## YOU'LL ALSO NEED

MASKING TAPE | TAPE MEASURE / RULER | ISOPROPYL ALCOHOL | MICROFIBRE CLOTH | HEAT GUN (OPTIONAL)

**TIP** **Press firmly for 30 seconds along the full bond.** A brief warm-up with a heat gun helps the VHB tape reach full strength — avoid washing the car for 48 hours.

SECTION 01 · ALIGNMENT

REFERENCE 1 OF 2

# SET THE SIDE OFFSET.

Clean the bumper surface and dry-fit the canard. Align it to the references on this page and the next, mark the position, then mount. Work one side at a time and mirror the measurements for the opposite canard.

REFERENCE · FIGURE 1

1

### SIDE OFFSET — 56 MM

Align the outside corner edge of the mounting lip **56 mm** from the edge of the bumper, as shown in Figure 1.

FIG. 01 · 56 MM



SECTION 02 · ALIGNMENT

REFERENCE 2 OF 2

# SET THE FRONT GAP.

With the side offset set, fix the front of the canard using the two references below. Confirm both before mounting, then press the canard firmly in place.

## REFERENCES · FIGURE 2

**1**

### FRONT HEIGHT — 52.5 MM

Align the outside corner edge of the mounting lip at the front **52.5 mm** from the bottom edge of the bumper.

**2**

### TOP GAP — 12.5 MM

Align the top edge of the canard with the edge of the bumper until the gap is **12.5 mm**, as shown in Figure 2.

FIG. 02 · 52.5 / 12.5 MM



SECTION 03 · FINISHED — DONE

✓ BOTH CANARDS FITTED

# ENJOY!

Repeat the references mirrored on the opposite side and confirm the gaps are even on both canards before final mounting.

THANK YOU

## ENJOY THE NEW LOOK.

From everyone at ST-Trackparts — we appreciate you trusting us with your build, and the extra front-end bite.

NEED HELP?

## WE'RE HERE FOR YOU.

If there are any problems or you need any help, reach out — we'll get back to you fast.

→ **info@st-trackparts.com**

FIG. 03 · INSTALLED ON CAR

