

ST TRACKPARTS

STW-style tow hook installation guide

1. Remove the trim piece which covers the tow hook.
2. Hold the included stud behind the bumper supports, such that it's visible on the front.



3. Slide the tow hook onto the two studs, while supporting the stud.



4. Install the included nuts and washers to secure the tow hook and bumper.



5. Trim the cover and finish by reinstalling it!

