

ST TRACKPARTS

**E36 Sliderless Seat Consoles
Installation guide**

Tools needed:

- Socket wrench
- 17mm socket
- 17mm spanner (ratchet spanner recommended)
- 5mm hex bit

1. Loosely install the inside bracket.



2. Mount the seat to this bracket. You can tilt the bracket to make more room.

Use a 5mm hex bit or allen wrench to tighten the bolts completely.



3. Install the outside bracket. Use the button-head bolts to mount the bracket to the seat.



4. Now everything should be tightened except for the inside bracket to the floor.

Use a 17mm wrench to tighten the floor bolts. We can recommend a ratchet spanner if you have one.



5. Installation done. Enjoy!

